

# Qi SUPER SLIM Powerbank 5000mAh

## Manual

(2014/53/EU art. 10-8)

Battery Capacity:

5000mAh/3.85V/19.25Wh

Wireless Charger: 15W (Max)

Input: USB-C 5V/3A, 9V/2A, 12V/1.5A

Output: USB-C 5V/3A, 9V/2.22A, 12V/1.67A



(2014/53/EU art. 10-9 Simplified Declaration of Conformity)

C Two Products AB hereby declares that this product complies with the essential requirements and other relevant conditions of directive 2014/53/EU. The complete EU Declaration of Conformity is available at: [usb.nu](http://usb.nu) - search on article no: 16103 Model: M60

Electrical and electronic devices must not be disposed of with household waste according to the European WEEE directive. Their components must be recycled or disposed of separately because of toxic and hazardous components, if improperly disposed, it can cause lasting damage to health and the environment. As a consumer, you are required under the Electrical and Electronic Equipment Act (ElektroG) to dispose of electrical and electronic equipment properly at the end of its service life. Contact your local waste disposal company. With the CE mark we declare that the product is the basic Requirements and guidelines of European regulations.

C Two Products AB


Ridbanegatan 4,

S-213 77 Malmö

[info@ctwo.se](mailto:info@ctwo.se)



Made in China



## CHARGING THE POWERBANK

- Connect the USB cable to a switched on computer or USB wall charger (not included).
- Connect the USB-C plug with the USB-C port of the Powerbank.
- Once the charging process is completed the 4 LED indicator will be steady in white.

*Note: DO NOT charge and discharge the Powerbank at the same time.*

## CHARGING THE MOBILE

### Wireless Charging

Place the device to be charged with the backside on the charging surface, press the on/off button once, if the device is wireless chargeable, then the wireless operation LED lights up in green.

Press on/off button twice to turn off the wireless charging.

### Charging with USB-C cable

- Please keep the powerbank away from moisture and corrosive materials, please do not touch the device with wet hands.
- Store in a relatively dry and ventilated environment.
- Keep it away from fire and high temperature.
- Please do not let children or animals chew or suck on the device.
- Please do not dis-assemble, modify or repair your device without permission.
- Please do not place magnetic objects such as bank cards/passbooks/phone cards/registration cards on the charger.
- In case of infrequent use, charge the powerbank at least once every two months, and charge for at least 1 hour before storage.

Avoid serious drop, collision, friction or other impacts on the powerbank, if the powerbank is damaged, please stop using it. According to relevant laws and regulations, it is illegal to discard batteries as ordinary garbage, be sure to send used batteries to a local battery recycling center for disposal.

## **COMPATIBILITY**

iPhone 12/13/14/15 series or a phone with magnetic protective case.

## **SPECIFICATION**

Battery Capacity: 5000mAh/3.85V/19.25Wh

Wireless Charger: 15W (Max)

Material: Aluminiumalloy+PC

Input USB-C: 9V/2A

Output USB-C: 12V/1.67A

Device: 102.5x66x8.3mm

Weight: 143g

*Note: Automatically turns off after 30s under No-Load status*

*Green light: Wireless charging working*

*Whitelight: Battery capacity indicator.*

## **WHAT IS INCLUDED?**

1 x Magnetic Wireless Powerbank

1 x Type C cable

1 x Manual