Sonic Touch Toothbrush







DESCRIPTION:

Achieve whiter teeth and better oral health with our Sonic-Touch toothbrush. Nothing beats it. With up to 45,000 brush movements per minute, our Sonic-touch toothbrush far surpasses a conventional toothbrush. Choose from five different modes to find the one that suits you best. When you have found the mode you would like to use and the light is green, you can adjust the brushing intesity by holding down the lower button. Start with a quick press of the button and turn off with a single touch. The toothbrush vibrates every thirty seconds to remind you to change brushing positions and automatically turns off after two minutes – the recommended brushing time. If you wish to continue, simply restart the toothbrush. The unique brush head monitors how often and how hard you brush. When the bristles turn white, it's time for a replacement. Brush heads are available for purchase at sonic-touch.com or here on our website. With up to 60 days of battery life, you won’t need to charge the toothbrush frequently. When the battery starts to run low, a red light will blink. While charging, the battery indicator blinks, and when fully charged, the light turns green for ten seconds before switching off. The toothbrush is then ready for use again. Buy Extra Brush heads: Sonic Touch brush heads

SPECIFICATION:

Art No.	19083

-	Qty _	Price/pcs _	Total order _